

Netwatch

- [Summary](#)
- [Properties](#)
- [Type-specific options](#)
 - [ICMP probe options](#)
 - [TCP-CONNECT/HTTP-GET probe options](#)
 - [TCP-CONNECT pass-fail criteria](#)
 - [HTTP-GET probe pass/fail criteria](#)
- [Probe statistics/variables](#)
 - [Generic:](#)
 - [ICMP:](#)
 - [TCP:](#)
 - [HTTP:](#)
 - [HTTPS:](#)
- [Logs](#)
- [Status](#)
- [Quick Example](#)

Summary

Netwatch monitors the state of hosts on the network. Monitoring can be done with the following probe types:

- 1) ICMP - pings to a specified IP address - hosts, with an option to adjust threshold values
- 2) Simple - uses ping, without use of advanced metrics
- 3) TCP conn, to test the TCP connection
- 4) HTTP GET/HTTPS GET, request against a server you are monitoring

For each entry in the Netwatch table, you can specify an IP address, ping interval, and console scripts. The main advantage of Netwatch is its ability to issue arbitrary console commands on host state changes.



Since 7.4, Netwatch functionality has been expanded, prior versions only support simple ICMP probes. While upgrading to the new version, old Netwatch entries will be unchanged, reporting probe type "simple" - preserving the same functionality.



Default Netwatch values are always used - **even if they were not defined** by the user. Make sure to check the "status" page of the probe to see if the default thresholds are appropriate for your use case. Default threshold values can be found under the "probe options" section on this page.

Properties

Sub-menu: `/tool/netwatch`

Property	Description
host (Default: "")	The IP address of the server to be probed. Formats: <ul style="list-style-type: none">- <i>ipv4</i>- <i>ipv4@vrf</i>- <i>ipv6</i>- <i>ipv6@vrf</i>- <i>ipv6-linklocal% interface</i>
type (icmp/ tcp-conn/http-get/simple; Default: simple)	Type of the probe: <ul style="list-style-type: none">- icmp - (ping-style) series of ICMP request-response with statistics- tcp-conn - test TCP connection (3-way handshake) to a server specified by IP and port- http-get - do an HTTP Get request and test for a range of correct replies- simple - simplified ICMP probe, with fewer options than "ICMP" type, used for backward compatibility with the older Netwatch version
interval (Default: 10s)	The time interval between probe tests

timeout (Default: 3s)	Max time limit to wait for a response
src-address (Default: "")	Source IP address which the Netwatch will try to use in order to reach the host. If address is not present, then the host will be considered as "down".
start-delay (Default: 3s)	Time to wait before starting probe (on add, enable, or system start)
startup-delay (Default: 5m)	Time to wait until starting Netwatch probe after system startup
up-script (Default: "")	Script to execute on the event of probe state change 'fail' --> 'OK'
down-script (Default: "")	Script to execute on the event of probe state change 'OK' --> 'fail'
test-script (Default: "")	Script to execute at the end of every probe test

Netwatch executes scripts as *sys user, so any defined global variable in the Netwatch script will not be readable by for an example a scheduler or other users



Netwatch is limited to *read,write,test,reboot* script policies. If the owner of the script does not have enough permissions to execute a certain command in the script, then the script will not be executed. If the script has greater policies than *read,write,test,reboot* - then the script will not be executed as well, make sure your scripts do not exceed the mentioned policies.

It is possible to disable permission checking for RouterOS scripts under */system/scripts* menu. This is useful when Netwatch does not have enough permissions to execute a script, though this decreases overall security. It is recommended to assign proper permissions to a script instead.

Type-specific options

All config options specific to one probe type (e.g. icmp's packet-interval) are ignored for other probe types (tcp-conn, http-get).

ICMP probe options

Property	Description
packet-interval (Default: 50ms)	The time between ICMP-request packet send
packet-count (Default: 10)	Total count of ICMP packets to send out within a single test
packet-size (Default: 54 (IPv4) or 54 (IPv6))	The total size of the IP ICMP packet
thr-rtt-max (Default: 1s)	Fail threshold for rtt-max (a value above thr-max is a probe fail)
thr-rtt-avg (Default: 100ms)	Fail threshold for rtt-avg
thr-rtt-stdev (Default: 250ms)	Fail threshold for rtt-stdev
thr-rtt-jitter (Default: 1s)	Fail threshold for rtt-jitter
thr-loss-percent (Default: 85.0%)	Fail threshold for loss-percent
thr-loss-count (Default: 4294967295 (max))	Fail threshold for loss-count

TCP-CONNECT/HTTP-GET probe options

Property	Description
port (Default: 80)	TCP port (for both tcp-conn and http-get probes)

TCP-CONNECT pass-fail criteria

Property	Description
----------	-------------

thr-tcp-conn-time (Default: 0 0:05...00:30)	Fail threshold for tcp-connect-time, the configuration uses microseconds, if the time unit is not specified (s/m/h), log and status pages display the same value in milliseconds.
--	---

HTTP-GET probe pass/fail criteria

Property	Description
thr-http-time (Default: 10s)	Fail threshold for http-resp-time
http-code-min (Default: 1 00)	OK/fail criteria for HTTP response code.
http-code-max (Default: 2 99)	Response in the range [http-code-min , http-code-max] is a probe pass/OK; outside - a probe fail. See mozilla-http-status or rfc7231

Probe statistics/variables

You can view statistics and use these variables in scripting, keep in mind that variables containing "-" must be written like this, for example, "done-tests" would be `$(done-tests)`

Generic:

Property	Description
name	user added name for Netwatch entry
comment	user added comment
host	host that was probed
type	probe type
interval	interval
timeout	timeout
since	The last time the status change happened
status	current status of probe
done-tests	total count of probe tests already done so far
failed-tests	count of failed probe tests

ICMP:

Property	Description
sent-count	ICMP packets sent out
response-count	Matching/valid ICMP packet responses received
loss-count	number of lost packets
loss-percent	number of lost packets in percent
rtt-avg	mean value of rtt (packet roundtrip time)
rtt-min	min rtt
rtt-max	max rtt

rtt-jitter	jitter (= max - min) of rtt
rtt-stdev	standard deviation of rtt

TCP:

Property	Description
tcp-connect-time	time taken to establish a TCP connection

HTTP:

Property	Description
http-status-code	HTTP response status code (200 OK, 404 Not Found, etc.). See mozilla-http-status or RFC7231

HTTPS:

Property	Description
http-status-code	HTTP response status code (200 OK, 404 Not Found, etc.). See mozilla-http-status or RFC7231

Logs

On each probe's OK/fail state change:

- probe identification info and OK->fail or fail->OK is printed to info level
- detailed probe stats and config is printed to debug level

Status

Command `/tool/netwatch/print` will show the current status of Netwatch and **read-only** properties:

- since - Indicates when a state of the host changed last time;
- status - Shows the current status of the host;
- host - address being monitored

Quick Example

Here we will use a simple ICMP check to host with IP 8.8.8.8:

```
[admin@MikroTik] > /tool/netwatch add host=8.8.8.8 interval=30s up-script=":log info \"Ping to 8.8.8.8
successful\""
```

Afterward, in the logging section we can see Netwatch executed script:

```
[admin@MikroTik] > log print where message~"8.8.8.8"
08:03:26 script,info Ping to 8.8.8.8 successful
```